

Technical Manual

Uh-Huh!



SIERRA. INSTRUMENT COMPANY

Sierra Instrument Company

P.O. Box 66289
Portland, OR 97290
(503) 761-9632 • fax (503) 761-4939

Set up for Session Series

From the in-case position, figs 20 & 22, insert the legs into the leg sockets and tighten the leg lock handle. The small pin on the leg stub must be in line with the slot of the leg socket. Insert the stub until the leg is even with the guitar body, then rotate the leg 90 degrees to be square with the body and the front legs pedal rack mounting pins facing the front, and the back legs height adjustment facing the back.

Install the pedal rack by sliding the lock plates to the outside of the leg slots and position the rack on the legs so that the pins on the legs are inserted into the pedal rack. Then slide the locks in place and tighten the knobs. The pedal rods are numbered with number 1 at the string tuning end of the guitar. Install the hook end of the rod on the cross shaft arm in either hole. (The hole closest to the shaft will provide the shortest pedal action and the hole farthest from the cross shaft will provide the easiest pedal action.) Then attach the slide ball end on the ball at the pedal. Again, there are three positions to adjust pedal action to your preference.

The adjustment section is being up dated for the new session series. When this is completed it will be made available for the session owners. We have included three photos at the back of this **manual (figs 20. 21 & 22)** for reference help until the manual is updated.

Set up for Royalty and Crown Series

Loosen leg knobs and turn leg into up position; the snap lock will automatically align the leg. On the front leg there are two pins which match up with holes in the pedal rack. Slide pedal rack lock plates away from the end of the pedal rack and align the pins to the holes. Now, slide the plates toward the ends of the pedal rack and tighten the knobs. Pedal rods are numbered; #1 is closest to the tuning keys. Install the pedal rod slip ball joint on the ball of the pedal, then put the other end into the cross shaft ball with slip ball joint. Centering leg lock knobs for aesthetic reasons may be done with shims available from the factory.

Break down:

Reverse above procedure but slightly loosen legs before placing the guitar in its case. After folding the legs in the case, re-tighten each leg to keep it from moving while in the case.

Electric circuit & pickup - removal and replacement:

Doubles: on back side of guitar (closest to player) with guitar in playing position and player seated behind.

1. Three-way rocker switch closest to changer is the neck selector switch; moving the switch to right activates the C6 (back neck); moving the switch to center activates both necks; moving the switch to left activates E9 (front neck).
2. Three-way rocker switch in center controls the three pickup tones for the front neck (E9).
3. Three-way rocker switch furthest to left controls the three pickup tones for the back neck (C6).

Singles: one three-way rocker switch on back side of guitar (changer end) controls the three pickup tones.

Pickups

To please the varying tastes of our customers, we developed and pioneered modular pickups. Custom pickups are wound with different tonal qualities in mind. The opportunity for the player to select from our many different pickups allows him to custom-tailor his guitar to his own tonal desires.

Pickup removal & replacement

Slide out present pickup. Notice there is a dove-tail track with three brass spring-loaded pins. Using the un-lipped end of the pickup, **gently** depress the three pins and mate the dove-tail on pickup with the track, and slide the pickup into place. **Alignment and pin depression is essential!**

Tuning

To better understand tuning procedures of your Sierra, study fig. 2, and compare to your guitar. Fig. 2 shows the relationship from pedal to changer. A hex capped pull rod is installed with 2 or 3 nylon cylindrical bushings (1 or 2 lengthwise, 1 crosswise). These bushings are what contact the changer when a pedal is used. One short bushing accommodates the raise holes, (fig. 1, rows A, B, C); one long and one short accommodated lowers, (fig. 1, rows D & E). The properly used rod is then guided through the proper changer hole for raises or lowers. A bell crank with a threaded barrel shape nut is then aligned and tightened on the cross shaft. The rod is then threaded through the nylon nut. When the cross shaft is rotated by a pedal or lever, the bell crank on it moves the pull rod. The cylindrical bushings thereby come into contact with the changer finger, moving it to make a change.

Tuning pedals & knee levers

Tuning a Sierra is not complex. The guitar is tuned open to a electronic tuner, fork, or whatever, and then tempered to sound pleasing to your ear. Pedals and knee levers are tuned at the right endplate. With guitar in playing position, the 3 top most rows in the changer are raises, fig. 1, the bottom 2 rows are lowers. To adjust, turn brass pull rod hex cap clockwise to increase your change or counter-clockwise to decrease it. This is the same for raises or lowers. **Caution: do not over-tighten these rods.** A good rule is to leave 1/32" to 1/16" of free-play in each rod. (This is explained in the "trouble shooting" section.)

Half stops

The Sierra half stop consists of an extra bell crank on the lever shaft and a special half stop rod. This rod, fig. 4, visible at the endplate, is easily recognized from the others by a spring mounted on it. The normal pull rod operates the changer, e.g. 2nd string E9th D# to C#. The spring loaded half stop rod has no nylon bushings and will not effect the changer. It travels freely until the spring begins to compress. This point of pressure gives the knee lever a defined stop-feel and is adjusted at the endplate to the half tone between a whole step, as D between the D# and C#. The amount of "feel" is also adjustable by lengthening or shortening the preset compression of the spring by resetting of the lock nuts or lock collars holding the spring. When resetting for "harder feel," make sure spring does not fully compress before full tone note can be made.

Changer

The Sierra changer is an all-pull triple raise/double lower system. This means that any string can be raised 3 separate times and lowered 2 times. To accommodate the players with more complex tuning specs, we offer additional raise-and-lower capabilities. By means of a "tandem" system the Sierra can easily achieve these multi-change situations and still be tunable at the endplate. In fig. 5, you can see that the two raises are utilizing shafts #1 and #2, E to F and E to F#. To get another raise, E to F# again, a rod with no bushings is threaded through a bell crank in position D. On it is a collar with set screws (X) and a two holed slide block (Y). The rod on #1 passes through (Y) with a collar (Z) which is tightened on the pull rod ahead of the slide block (Y). As #3 is moved, its collar moves the slide block which contacts the collar on #1. Since #3 has no bushings, it will not affect the changer; #3 works directly on rod #1, which in turn will affect the changer.

To tune

Turn pull rod either clockwise or counterclockwise, turning #3. Clockwise will decrease the distance between X & Y, thus raising a greater distance; counter-clockwise will do just the opposite.

Change-lok

The "change-lok" is used for locking a change or changes into place; it maintains the change until released. Change-loks are hand-operated, and usually used with the universal tunings. The E9th with change-lok on E's to E-flat gives a 136th. The player can then use all his jazz pedals without being hampered by holding a knee lever in for an extended time. When he releases it, he is back to Nashville E9th. Fig. 13 depicts this mechanism. The change-lok is tuned as follows:

1. Adjust change-lok cam so that maximum travel is opposite knob direction.
2. Adjust change-lok and mount plate so that with the cam engaged the knee lever is pressed hard against stop.

The change-lok, when engaged properly, will put the KL cam in the same position it would be if the normal KL was engaged.

Leverage Selection

Theory

To change your guitar tuning you have to know a little something about selecting proper leverages at both the changer and bell crank. Fig. 3 shows these two parts as the guitar is upside down.

Changer: raise holes are rows A, B, & C. Row 'B' is easier to pull than row 'A,' but it also requires more movement to move a string a given distance than does row 'A.'

Lower holes: 'E' is easier than 'D,' but does not pull as quickly.

Bell crank: slot 1, that nearest the cross shaft, is the easiest but longest pull. As you move upward, slots 2,3, & 4 become progressively stiffer but quicker; usually slots 2 & 4 are best suited for whole-step changes. All slots will accommodate half tone changes. The goals for selecting optimum leverage are synchronization of all changes on a pedal or knee lever and attain desired effort.

Procedure for selection

Determine which change on the pedal takes the most distance to be achieved.

General rule is that of the two strings tuned an octave apart, fig. 16, 5th and 10th strings B's, making the same change (fig. 16, pedal 1), the higher pitch (lighter gauge) string will require more distance to change.

In fig. 16 next to each pedal change there is a circled number. These tell you the factory-set leverages on a SCO-10 crown. Pedal 1 on this chart, both changes are B to C#.

By each C# is the recommended leverage. On the 5th string (A3) and on the 10th string (B3). This means the pull rod passed through row 'A' of the changer and slot 3 for the 10th string. Note: we already know, as discussed earlier in this section, that row 'A' in the changer is a quicker throw but stiffer feel than row 'B.'

Now in fig. 16, pedal #1, both changes are positioned in slot 3 of the bell crank. To compensate for the greater distance the 5th string B requires to reach C# [than does the 10th string] we place it in the faster traveling row 'A' and the shorter 10 string change in slower row 'B.' This equalizes the two changes and allows them to pull as evenly as possible. At times equalization will have to be compromised on a certain pedal, either for quantity of changes or better equalization on a more used pedal. There are no ironclad charts that will cover all tunings. When making changes, experiment with leverage and using the above guidelines; you will be able to obtain almost any

thing on your Sierra.

Making Changes

Bell crank relocation:

To change bell crank to a different string:

1. Back out pull rods on bell crank to be moved.
2. Loosen screws on bell crank.
3. Move bell crank to new string alignment position. If there is pull rod interference, back them out and re-pass through aligned bell crank.
- 4., Tighten bellcranks into place.
5. Refer to leverage section and select your leverage points. Properly bush pull rods for raise or lower (short & long for lower, short only for raise) then attach through selected changer rows to bell crank slots.
6. Re-attach all other pull rods which were loosened.

Bell crank addition and re-assembly:

1. Remove all pull rods attached to or passing through bell cranks on cross shaft where bell crank is to be added or relocated.
2. Loosen knee lever hub or pedal arm, set collars and spring arms. 3. Remove cross shaft by sliding it out back of guitar.
4. Add or relocate bell cranks.
5. Assemble by reversing sets 1 through 4.

Make sure all screws are tightened firmly, but do not over-torque.

Tuning new changes:

Pedal: if possible use strobe or electronic meter tuner.

1. Remove any stretch from new strings and tune open notes to their true pitches.
 2. Determine which one of the changes on the pedal will determine your pedal or lever throw. You will want to eliminate most of the free-play or "slop" in the pedal.
 3. If you have a tuner, you can actually determine the point of your longest change where (E) is too tight against (C), fig.10, and will affect your open note; then turn your pull rod clockwise until the tuner shows the open note is deviating from its original pitch, then back off 1-1/2 to 2 turns.
 4. With both rods determined to **not be tightened against changer**, move desired pedal and watch your tuner or play it by ear.
 5. Set cam (B) by tightening it to the rail at the point where your longest pull is, just past the desired note when (A) stops against (B).
 6. With your cam set (thus establishing your pedal throw) tune all other changes on that pedal to pitch. Usually you will be backing off these other pull rods.
 7. Re-check all the changes, with the addition of changes you may find your original note does not come perfectly up to pitch so:
 - A. Make sure string 'open' is still in pitch. (not stretched).
 - B. Then, if need be, loosen and re-tighten cam to accommodate true pitch on your original note.
- This procedure is the same as used at the factory. If you are having problems, repeat it. Most tuning problems are caused by some negligence or error in the execution of the above procedure.

Knee levers

Procedure as above; refer to fig. 11 if lever is moving left, to fig. 12 if lever is moving right, guitar in playing position. Be sure cap screw on mobile knee lever slave is tightened on cross shaft. This is also true on non-mobiles; they must be centered.

Trouble shooting

General tuning: it is important to realize that the Sierra guitar is a precision machine set up to operate within tuning specs set at the factory. Occasionally, through expanding his tuning, a player will exceed the original predetermined specs set up by us, (e.g.. different pedal action, different pedal throw length, extra long changes, new changes, etc..). To broaden the scope of your original tuning specs is no problem. The following section will describe the procedures necessary to achieve your goals.

Pedal travel (fig. 15)

To lighten: remove pedal rod ball end from center hole on pedal and move to hole nearest pedal bracket. The closer toward the pedal bracket the pedal ball end, the easier (but longer) it will be. Away from the pedal bracket the opposite is true (fig.15). Additional effort change can be achieved by adjusting rod end on cross shaft. Remember: when making a change, shorter is to make it harder. Also, keep in mind when changing mechanism advantage (lightness) of a change that it must be compatible with the setting of your cam stop - you may need more or less room.

Tension springs

Insufficient travel may be caused at the tension springs, fig.14, on underside of changer. Push a lowering change while looking at the tension springs, (B). Observe the lowering finger (C) will move forward; this should only happen while lowering. If this is occurring during a raise, it will tend to cancel your raise. Tighten the small screw at the right endplate (D) while working the pedal. When the movement is stopped turn screw 1-1/2 to 2 complete turns and you should have a greater raise of pitch to your change. (This should be done with the raise having most travel on any given string, such as the 3rd pedal E to F# instead of left knee lever right E to F.

Untrue return

If a change does not return all the way to its original pitch make sure the pull rods are not overtightened. Observe underside of changer, fig. 14, -if the change lowering finger (C), or the offending string is misaligned, and not pulled back to the rear (E) bushing, tighten the tension until unalignment is corrected. A good preliminary test for rod over-tightening is to check changer bridge, fig.14., Item A, at the ball end of the string. If the string in question is over-tightened, it will be out of alignment with the other changer bridges. Loosen the next rod and follow tuning procedures.

Insufficient travel

Follow pedal tuning section procedure; you may need to re-set your cam.

Excessive travel

Check all pulls on pedal or knee lever and follow tuning procedures section, removing excess slack.

Slippage

Slippage on cross shafts should not occur. If it does the component needs to be re-torqued.

Look at shaft in question. If only one bell crank is out of alignment with the others, loosen its pull rod and loosen the bellcrank, re-align, then carefully tighten it. (You can test this by hand against the other.)

If all bell cranks are not close to 90° from body, the pedal arm or knee lever hub has moved. If this is the condition, reposition and tighten.

Lubrication

It is advisable every three months to sparingly apply lubricant to bell cranks, nylon barrels, underside of the changer mechanism and **most important** to the right moving knee lever ball joint knuckles. **Do not over-cube**, as dust and dirt will adhere to the lubricant.

Strings

Two things to check periodically: string alignment through nut rollers. Tension screw on the Grover tuning keys, Royalty models, must be tight enough to avoid tuning key slippage.

Adjustments

Both the front and rear legs are adjustable for height, although custom leg sizes may be specialordered for people who want shorter or longer inserts to accommodate them.

Front. loosen setscrews on square leg portions. Re-adjusting this might cause you to have to readjust pedal rods.

Rear quick release butterfly knob-in-groove.

Pedal rods

Loosen nuts at either clasp to shorten or lengthen.

Mobile knee levers (fig. 8 & 9)





The gap between the left and right knee levers on either leg may be narrowed or widened by moving mobile knee levers.

Loosen all pull rods 3 or 4 turns on that knee lever. Loosen plate cover (A).

Loosen (D) at the 10/32 nut through (E) to close the gap. *Reset position of (A) while holding (F) straight up 90°.* Tighten (A)

Re-tighten all pull rods properly and re-tune.

On RKR, check to see leg will fold without hitting hub.






FIG. 5






Fig. 6






Fig. 9




FIG. 10







FIG. 11







FIG. 16 PEDALS

	GA.	TUNE	KNEE-LEVELS					
			1	2	3	4	5	
1	.013	F#						
2	.015	D#						(D4) D
3	.012	G#		(A3) A				
4	.014	E			(A3) F# (B4) F		(D4) E	
5	.018	B	(A2) C#		(B3) C#			
6	.022	G#		(A1) A				
7	.026	F#						
8	.030	E			(B2) F		(D4) E	
9	.036	D						(D4) C
10	.038	B	(B2) C#					

Gearless String Installation Procedure




Fig. 17

Steps to install a string

1. Rotate tuning adjustment screw fully counter-clockwise to allow the tuning lever to pivot UP and against the string roller nut (point "A"). This ensures that there will be adequate leverage ("moving room") to bring the string up to the proper pitch in a later step.
2. Rotate string locking screw counter-clockwise two or three revolutions to allow space for string to pass **under** the locking screw head.
3. Remove any pieces of broken string from the unit, **ESPECIALLY** in the changer end. Use a pair of needle-nose pliers to remove the ball-end from the interior mechanism of the changer.

String adjustment/replacement procedure, continued




Fig. 18

- Step 3. Insert string end through hole as depicted above and wrap string **clockwise** around the string locking screw. **Do not wrap string completely around the screw shaft and do not tighten the lock screw at this time!**
- Step 4. Thread string end through the string puller. Wrap string around the puller four or five times. This will allow you to be able to pull the string tight (step 5).
- Step 5. Remove slack from string by pulling in direction shown in figure above. Ensure that string rides on roller properly and that the string is on the center of the changer end lever. As you pull the string taut, ensure that the tuning lever is as close to the string roller nut as possible (refer to "Point A"). Continue to pull the string tight until you hear the pedal changer unit snap into position. Carefully hold string at this tension. Tighten the string locking screw with appropriate Allen wrench. The string should not slip when you relax the pulling tension on the string puller.

String adjustment/replacement procedure, continued




Fig. 19

Step 6. The string may now be brought up to the correct reference pitch by adjusting the tuning adjustment screw clockwise. (It should be noted that in the event you have pulled the string - with the string puller - higher than the standard reference pitch, the string tension may be relaxed a little by loosening the string locking screw very slowly. As string tension relaxes, tighten the locking screw to secure the string.) Continue tuning with tuning adjustment screw. With the string at the proper tension (note), exercise the appropriate pedal/lever a few times to ensure string does not slip or detune.

Remove excess string at the locking screw head with a pair of side cutters.

Manufacturer's Comments: It may take a few times for you to become proficient with this procedure, but the many advantages offered by the Sierra Gearless Tuner is well worth the effort. After a very few string changes, you will be able to change a string much faster than with the Grover type geared tuners.




Fig. 20




Fig.21




Fig.22